

TRAINING SYLLABUS DFL7340 Maintenance 1

Intended Trainees

- who has already completed the "Operation 2" course (or has equivalent operation skills)
- · who conducts periodic maintenance of the machine

Course Objective

To enable trainees to safely and precisely perform the periodic maintenance and consumable parts replacement described in the Maintenance Manual of the machine

Schedule

Day 1	Orientation
	Introduction of Training Center facility/staff and schedule
	Interpret Safety Precautions
	Interpret the Machine Components and Functions
	Replace the Chuck Table
	Change the Frame Size
	Adjust the Air Pressure Sensor
	Use the LOG VIEWER screen
	Use the LOG ANALYZER screen
	Perform the Laser Maintenance (4.0 screen) Tasks
	Perform the Engineering Maintenance Tasks
	Check the Power Meter Light Receiving Unit and its Periphery
	Replace the Coolant of the Chiller
Day 2	Check and Replace the Air Injection Gun Filter
	Clean the Vacuum Ejector
	Grease the X-axis
	Grease the θ-axis Sensor Assembly Section
	Grease the Y-axis
	Grease the Push-pull Axis
	Grease the Frame Centering Axis
	Replace the Air Clean Unit Consumable Part
	Replace the Halogen Lamp
	Replace the Pad of the Transfer arm
	Replace the Solenoid Valve

Interpret the Remedied for Problems Invoking Error Code Indication

Q & A

Closing

Issuing training certificate

Request for filling in questionnaire sheet

Note

The specification of the DFL7340 varies according to the customer in terms of function and accessories. For this reason, please note that the machine to be used in the training may not have the same specifications as your machine and may not be equipped with the optional accessories that your machine has.